

## Bartex Collection Washing Instructions

### Recommended for

**Bartex Optigraphic™**  
**Bartex Diplomat™**  
**Bartex Optibrush™**

No.	Process	Comments	Time	Water Level	Temperature
1.	Flush		2-3 Min.	Medium	49°C
2.	Flush	Optional	2-3 Min.	Medium	49°C
3.	Break		2-3 Min.	High	49°C
4.	Rinse		2 Min.	High	Cold
5.	Rinse		2 Min.	High	Cold
6.	Extract	Low Speed	1-2 Min.		
7.	Shake Out	Drum Turning	1 Min.		
8.	Extract	Max. 250G	3-5 Min.		
9.	Dry	Optional	5-10 Min.		82°C (Basket Temp.)
10.	Cool Down		5 Min		

### Additional Recommendations

1. It's recommended that Optibrush mats are washed separate from other mats.
2. Optigraphic & Diplomats can be washed together with other SDN mats
3. For Heavy Soiled Mats, increase temperature up to max. 71°C
3. Break should not exceed pH of 9,5; use low pH non-ionic detergents
4. Do not overdry mats; Basket-temperature of dryer should not exceed 82°C
5. If mats are not dried, final rinse can be increased to 49°C. This will reduce moisture retention following extraction
6. Lay Mats flat following removal from washer; allow mats to cool before rolling